

HH-LSYT CAMPING TENT

Please Keep For Future Reference



IMPORTANT - Please Read Instructions Fully Before Assembly Or Use

These instructions contain important information which will help you get the best from your equipment and ensure safe and correct assembly, use and maintenance.

If you need help or have damaged or missing parts, call the Customer Helpline: **0330 124 0718** (Opening hours: Mon-Fri 9:00am-5:00pm) or Email: **customerservices@fit4home.co.uk**

IMPORTANT SAFETY INFORMATION

IMPORTANT SAFETY INFORMATION

BE SURE TO READ THE ENTIRE MANUAL BEFORE YOU ASSEMBLE OR OPERATE YOUR ITEM. IN PARTICULAR, NOTE THE FOLLOWING SAFETY PRECAUTIONS:

1. Allow at least 6m spacing between tents and caravans or other vehicles.
2. Never use fuel-burning devices (e.g., disposable barbecues, camping stoves, camping heaters, lanterns, and charcoal grills) inside a tent.
3. Never use candles in or near a tent - torches are much safer
4. Flammable liquids and Liquefied Petroleum Gas cylinders should be kept outside the tent
5. Oil burning appliances are not recommended
6. Cooking appliances should never be used in small tents
7. Never light a candle or have any other kind of flame burning apparatus in or near to a tent
8. Cook outside and away from the tent
9. Don't smoke inside the tent and keep any flammable material away from the cooking area
10. Have an escape plan


CAUTION: Read all instructions carefully before operating this product. Retain this Owner's Manual for future reference.

PARTS LIST


No.	Description	Qty
01	Holdall Bag	1
02	Large Pole Bag	1
03	Small Parts Bag	1
04	Tent with fixed groundsheet	1
05	Orange Pole (PART A)	1
06	Black Pole with Red Band (PART B)	4
07	Grey Pole (PART C)	2
08	Black Pole with Green Band (PART D)	2
09	Black Pole (PART E)	2
10	Black Pole with Hook (PART F)	2
11	Black Pole with Hook (PART G)	2

12	Plain Black Pole with Silver Ends (PART H)	2
13	Tent Pegs (PART I)	12
14	Guyline Ropes (PART J)	8
15	Guyline Rope Guides (PART K)	8
16	Top Sheet (PART L)	1
17	Room Divider	1

PARTS LIST




DIAGRAM



ASSEMBLY INSTRUCTIONS

STEP 1-2

1. Lay out the tent groundsheet flat on the ground, where you would like to pitch the tent
2. Assemble each folded grey pole (PART C) into 2 long grey poles



STEP 3-5

3. Feed each one of the assembled grey poles diagonally through the orange tunnels, from one corner to the other.
4. Assemble the folded orange pole (PART A) to create 1 long pole.
5. Feed the orange pole through the horizontal orange tunnel.



STEP 6-8

6. Feed the end of each grey pole, into one of the slots of the 3-sided black connectors, which are already attached to the tent.
7. Feed each end of the orange pole into one of the slots, of the 2-sided black connectors, which are attached to each side of the tent.
8. Assemble each of the folded black & red poles (PART B) into 4 long poles.



STEP 9-10

9. Slot one end, of each black & red pole, to one side of the 3-sided black connector, on each corner of the tent.
10. Slot the tent pole pin (That comes attached to the tent with the pole ring) into the other end of each of the black & red pole to secure this in place.



ASSEMBLY INSTRUCTIONS


STEP 11-12

11. Fix each black & red pole in place via the black clip attached to the tent
12. Assemble each of the folded black & green poles (PART D) into 2 long poles.



STEP 13-15

13. Slot one end, of each black & green pole, to the other side of the 2-sided black connector, on each side of the tent.
14. Slot the tent pole pin (That comes attached to the tent with the pole ring) into the other end of each of the black & green pole, to secure this in place.
15. Fix each black & green pole in place via the black clip attached to the tent



STEP 16-18

16. Assemble each of the folded black poles (PART E) into 2 long poles.
17. Slot each end, of each black pole, to the remaining side of the 3-sided black connectors, on the front and the back of the tent.
18. Fix each black pole in place via the black clip attached to the tent.



STEP 19-20

19. Raise the tent, this will take some co-ordination.
20. Tie the attached string, in the middle of the tent to fix the poles in place.



ASSEMBLY INSTRUCTIONS

STEP 21

21. Attach the guylines (PART J) to the orange windbreakers and peg into the soft ground with the guylines rope guides (PART K) and tent pegs (PART I) to secure the tent in place.




STEP 22

22. Clip the tent cover (PART L) into place via the green clips and Velcro strips which are attached to the tent. Adjust them as required.



STEP 23 - 26

- 23. For the canopy, assemble the short black poles (PARTS F, G, H) to create 2 long black poles
- 24. Feed the silver end of each assembled black pole, through the awning guide and attach 2 guylines.
- 25. Secure by pegging the guylines into the ground.
- 26. Your tent is now set up and ready.



FIT4HOME LTD

Fit4home is an online business which aims to provide high quality Exercise, Fitness and Outdoor products. At Fit4home we stock various items such as Tents, Garden Furniture, Treadmill, Exercise Bikes etc and aim to provide an excellent service to each and every one of our valued customers.

Fit4home employs a dedicated customer service team to ensure the consumer is provided with the best service and experience. For any queries or issues feel free to contact us via e-mail or phone.

As an online business we sell our products independently via our website, and we also trade from established markets such as Amazon and eBay. As an established business we endeavour to earn the confidence of the customer, it is for this reason that we try our utmost best to dispatch products the same day using a next working day delivery service to all UK mainland areas.

Along with the customer service department, Fit4home consists of hard-working and reliable technicians and designers who aim to meet the needs of our customers.

We offer a market leading 12 month warranty, which is simple and hassle free.

**Fit4Home© Ltd
Hours of Business: 9am - 5pm
Website: www.fit4home.co.uk
E-mail: customerservices@fit4home.co.uk**

